



The Critical Path in Maintenance Starts and Ends With Bolting.

TOOL MODEL: TTP-1 PRESSURE / TORQUE CONVERSION CHART

PRESSURE		TORQUE		
psi	bar	ft-lbs	kgf-m	N-m
20	1.38	301	42	408
25	1.72	376	52	509
30	2.07	450	62	611
35	2.41	525	73	712
40	2.76	600	83	813
45	3.1	678	94	920
50	3.45	757	105	1026
55	3.79	836	116	1133
60	4.14	915	126	1240
65	4.48	994	137	1347
70	4.83	1073	148	1454
75	5.17	1152	159	1562
80	5.52	1231	170	1669

