

# TORCTOOL

TOOL MODEL: TTX-21

## PRESSURE/TORQUE CONVERSION CHART

### Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	2716	376	3682	104
1600	2903	401	3935	110
1800	3276	453	4441	124
2000	3649	505	4946	138
2200	4025	557	5456	152
2400	4401	609	5965	165
2600	4777	661	6475	179
2800	5153	713	6985	193
3000	5529	765	7495	207
3200	5911	817	8013	220
3400	6293	870	8531	234
3600	6676	923	9050	248
3800	7058	976	9568	262
4000	7441	1029	10087	276
4200	7825	1082	10607	290
4400	8209	1135	11128	303
4600	8593	1188	11649	317
4800	8977	1242	12170	331
5000	9361	1295	12690	345
5200	9746	1348	13211	358
5400	10130	1401	13733	372
5600	10515	1454	14254	386
5800	10899	1507	14775	400
6000	11284	1561	15296	414
6200	11673	1614	15824	427
6400	12062	1668	16352	441
6600	12452	1722	16880	455
6800	12841	1776	17408	468
7000	13231	1830	17936	482
7200	13622	1884	18465	496
7400	14012	1938	18995	510
7600	14403	1992	19525	524
7800	14794	2046	20055	538
8000	15185	2100	20585	552
8200	15573	2154	21111	565
8400	15962	2207	21638	579
8600	16350	2261	22164	593
8800	16738	2315	22690	607
9000	17126	2369	23217	620
9200	17524	2424	23756	634
9400	17922	2479	24295	648
9600	18320	2534	24835	662
9800	18718	2589	25374	676
10000	19116	2644	25913	690