

TORCTOOL

TOOL MODEL: TTZ-2

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	269	37	365	104
1600	288	40	391	110
1800	327	45	443	124
2000	366	51	496	138
2200	402	56	545	152
2400	439	61	595	165
2600	476	66	645	179
2800	512	71	694	193
3000	549	76	744	207
3200	586	81	795	220
3400	624	86	846	234
3600	661	91	896	248
3800	699	97	947	262
4000	736	102	998	276
4200	774	107	1049	290
4400	812	112	1100	303
4600	849	117	1151	317
4800	887	123	1202	331
5000	925	128	1254	345
5200	963	133	1305	358
5400	1000	138	1356	372
5600	1038	144	1407	386
5800	1076	149	1459	400
6000	1114	154	1510	414
6200	1152	159	1561	427
6400	1189	165	1612	441
6600	1227	170	1664	455
6800	1265	175	1715	468
7000	1303	180	1766	482
7200	1341	185	1818	496
7400	1379	191	1869	510
7600	1417	196	1921	524
7800	1455	201	1972	538
8000	1493	206	2024	552
8200	1531	212	2075	565
8400	1569	217	2127	579
8600	1607	222	2179	593
8800	1646	228	2231	607
9000	1684	233	2283	620
9200	1722	238	2334	634
9400	1760	243	2386	648
9600	1798	249	2438	662
9800	1837	254	2490	676
10000	1875	259	2541	690